









**STABLE
CAMPER**



Component	Qty	Image	Hardware
Jack Clamp	2		(1) Allen Wrench (for assembly)
Front End Tube Assembly	2		
Truck Bed Side Tube Assembly	2		
Front Storage Mount	1		(4) #10 x 1.5" Stainless Steel Flat Head Screws
Side Storage Hanger - Front	2		(8) #10 x 3/4" Stainless Steel Pan Head Screws
Side Storage Hanger - Rear	2		(8) #10 x 3/4" Stainless Steel Pan Head Screws
Extended Front Mount (Pre-2018)	2		(8) #10 x 1.5" Stainless Steel Flat Head Screws (4) #10-24 x 5/8" Flat Head Screws
Bumper Plate (2019+)	2		(4) 1 ¼" Hex Lag Bolts (4) Flat Washers (4) #10 Flat Head Screws (4) ¼-20 x 1 ½" Phillips Pan Head Bolts


General Notes:

- **Before you begin the installation, remove the camper from the truck and make sure it is leveled.**
- **All mounted assemblies will need to be securely attached with supplied hardware to the camper frame.**
- **Avoid drilling pilot holes too close to the edge of the camper frame.**
- **Check the front tubes and hanger mounts as well as the side tubes and hanger mounts for any possible clearance issues.**
- **Confirm that the tubes will not be interfering with the tie down hooks, water, or any connections under the camper overhang.**
- **Apply RV sealant to all holes.**
- **Wear proper safety equipment.**
- **Do not stand, sit or climb on Stablecamper.**
- **The 3M VHB tape used on the front and rear side storage hanger mounts is very strong and repositioning the mounts after they have been fixed to the camper is not advised. When installing the mounts, be sure of placement before removing the adhesive backing and attaching the mounts with the supplied hardware.**

Mount the jack clamps to the fixed portion of the jack.

Drivers Side

Passenger Side




Jack Clamp Assembly Exploded View



Vertical Placement of Jack Clamp

Vertical placement of jack clamp will vary depending on the maximum angle of the front tube.



Before attaching front mounts to the camper, set the front tube assembly where it will be installed, note location of the ball when maximum angle is reached. Place jack clamp just above that location.


Passenger Side

View: Front Face of Camper

Driver Side


Please refer to the install page that is appropriate for your camper.
Campers 2018 and older, with the bumpers located higher on the camper refer to page 8 for front mount install.
Campers 2019 and newer, with bumpers located lower on the camper refer to pages 9-10 for bumper plate install.

Do not drill pilot holes too close to the edge of the camper frame. Use RV sealant on any holes and around the mounts. Mounted assemblies will need to be securely attached with supplied hardware to the camper frame.



Extended Front Mount Detail For Campers 2018 and Older

There is a driver side and passenger side orientation to the front mounts. Position the front mounts so that they are mounting to the camper frame. Do not drill pilot holes too close to the edge of the camper frame. Use RV sealant on any holes and around the mounts.






Bumper Plate Install For Models 2019 and Newer

Remove Front Bumpers.
Clear area of debris including
old caulking/sealant.

Using the supplied (1 ¼") lag screws and flat washers, attach the Stablecamper bumper plates using the existing holes from the front bumpers. Apply RV sealant to the holes and around the fasteners as needed.


Attach Front Mounts with
supplied #10 flathead
screws. Don't forget to add
the predrilling and sealant....



Thread front tube into
secured front mount.



Attach bumpers with $\frac{1}{4}$ -20 x 1 $\frac{1}{2}$
supplied bolts to Stablecamper
plates.




Passenger Side

View: Front Face of Camper

Driver Side

Position the front hanger bracket so that it is centered on the front face of the camper and attaching to the camper frame. Make sure it is positioned such that the front tubes rest on the tube rests. Drill (4) 9/64" pilot holes and attach with #10 x 1.5" flat head screws.



View: Side Face of Camper

- Before installing the storage mounts for the side tubes on the underside of the camper, confirm that the distance between the hanger mounts is the same as the installed length of the Stablecamper before drilling pilot holes.

Installed length
of Stablecamper


****The 3M VHB tape used on the front and rear side storage hanger mounts is very strong and repositioning the mounts after they have been fixed to the camper is not advised. Be sure of placement before attaching to camper.**

Zoomed in view of Front Hanging Mount

- Once stored on the hanging mounts, the tubes hang 2" below the underside of the camper. The exact placement of the hanging mounts will depend on the truck and your specific clearance needs. The mounts can be placed on the inside or the outside of the truck bedrail depending on your rig and setup.


Side Storage Front Mount Detail

For side tube storage, insert the ball through the keyhole (resting against the neck of the ball). Attach the rear end of the tube to it's rear hanger mount and rotate the tube to tension the tube as desired.





To remove the tube from the mount

1. Release the rear hanger mount and lower the end of the tube.



2. The ball now has clearance to be removed or inserted into the mount.

Side Storage Hanger Mount Rear Detail




****Please note: The 3M VHB tape used on the front and rear side storage hanger mounts is very strong and repositioning the mounts after they have been fixed to the camper is not advised. When installing the mounts, be sure of placement before removing the adhesive backing and attaching the mounts with the screws.**

Setup is easy:

Place the ball inside the socket on the jack clamp.

Insert the threaded end through the factory tie down bracket and secure with the knob.

Rotate the tubes to hand tighten the assembly just enough to take the slack out of the system. Do not overtighten.



For the front tubes, rotate the tube from the storage position on the front storage hook and place the ball inside the socket on the jack clamp.

Rotate the tubes to hand tighten the assembly just enough to take the slack out of the system.

Do not overtighten.

