

Rubber Bumpers

Before installing the rubber bumpers, make sure that you know the locations of your water tank and camper frame. If you aren't sure, contact your RV Dealer or Camper Manufacturer prior to installation. Make sure to be clear of any tanks or any potential interference or obstructions before drilling into the camper.

To install, determine mounting location for bumpers. Bumpers will need to be secured to the underlying frame structure on the front of the camper. Drill pilot holes. Use RV sealant on any holes and on the back of the mounts. Attach the bumpers to the camper frame using the included (2) 1/4" x 3" bolts with (2) 1/4" USS flat washers. Make sure that the bolts are secure.

(2) 1/4" x 3" bolts with
(2) 1/4" USS flat washers

